

Hydrologic Analysis with HEC-1 on a Personal Computer

Table of Contents

Chapter		Page
	List of Figures	v
1	Introduction	1
	1.1 Program Development	1
	1.2 Overview of the HEC-1 Package	1
	1.3 Acknowledgments	2
	1.4 Program Documentation	2
	1.5 Program Distribution	5
2	Program Installation Overview	6
	2.1 Computer Requirements	6
	2.2 Installation Options	7
	2.3 Contents of the HEC-1 Package Diskettes	7
	2.4 Memory Requirements	7
	2.5 Configuration of Computer System	7
3	HEC-1 Package Menu Program	9
	3.1 Purpose of the Program	9
	3.2 Program Operations	9
4	Input Data Files	12
	4.1 General	12
	4.2 Input Data Format	12
	4.3 Creating an Input File	12
	4.3.1 Using COED	13
	4.3.2 Using the Interactive Program, HEC1IN	15
	4.3.3 Other Methods	15
	4.4 Using HEC Data Storage System (DSS) for input Data	15

Table of Contents (continued)

Chapter		Page
5	Program Execution	16
	5.1 Executing HEC-1 Through the Menu System	16
	5.2 Executing HEC-1 Without the Menu System	17
6	Reviewing Model Results	18
	6.1 General	18
	6.2 HEC-1 Formatted Output File	18
	6.3 Using DSPLAY to Generate Graphs and Tables	19
	6.4 Using HEC-1 and DSPLAY Output in Other Programs	19
APPENDIX		
A	Interactive Input Developer for HEC-1 (HEC1IN)	20
B	Overview of DSPLAY for the PC	29

List of Figures and Tables

Figures	Title	Page
1	HEC-1 Computation Process	3
2	Recommended HEC Directory Configuration	8
3	HEC-1 Package Menu	9
4	Define Input/Output DSS Files Menu	10
5	HEC-1 Input Data File in COED Full Screen Mode	13
6	COED Help Screen	14
A.1	HEC-1 Menu System	21
A.2	Example Watershed	22
A.3	Job Initialization Data	23
A.4	Subbasin Connectivity Table	23
A.5	Subbasin Runoff Table	24
A.6	Gaged Precipitation Table	25
A.7	Channel Routing Table	25
A.8	Reservoir Routing Table	26
 Tables		
Table A.1	HEC-1 Input File for Example Watershed	27
Table B.1	Frequently Used DISPLAY Commands	30