

Creating a RAS Terrain for 2D Modeling

Cameron Ackerman, PE, D.WRE

USACE, Institute for Water Resources, Hydrologic Engineering Center






Overview

- Types of Terrain Models
- Building a Terrain Model
- Key Feature Considerations
- Cell Size Considerations
- Importing Terrain Information to RAS





A good model starts with **good terrain** ...





Terrain Model Types

- Triangulated Irregular Network (TIN)
- Triangulated points define surface allows for higher density in important areas.
- User-defined triangulation through points and break lines
- Grid
- Single value at regular intervals. Cell size determines surface resolution.
- Fast mathematical computations






Building a Terrain Model Verify and Process Points



- Start with raw data
- Remove 1st return data for vegetation, power lines, cows, etc.
- Bare earth terrain





Building a Terrain Model

Verify and Process Points

- Remove of points that are not necessary/incorrect in representing the ground surface
 - Redundant points (more points = more processing)
 - Bridge deck elevations
- Make sure to add important features
 - Top of roads
 - Top of levees
 - Top of floodwalls
 - Bridge approaches
 - Hydraulic structures
- Replace over-water returns with bathymetric data




Building a Terrain Model

Bare Earth Points





Building a Terrain Model Bare Earth Points






Building a Terrain Model Bathymetry Points







Building a Terrain Model Bathymetric Data Added





Building a Terrain Model Problems?






Building a Terrain Model Breaklines

- Breaklines are used to enforce triangle edges and elevations. They ensure that interpolation is done “correctly” along linear features.
 - Channel banks
 - Steep drops (drop structures, waterfalls)
 - Roadways
 - Levees
 - Bathymetry points



Building a Terrain Model Breaklines


- Breaklines with elevations insert points to enforce elevations and triangle edges





Bridges

- Removal of bridges from terrain data is important for 2D modeling.
- High ground directs flow – determined directly from ground surface model.
- 1D modeling place cross sections at appropriate locations as work around.






Terrain Cell Size Considerations

- Purpose – scale of model
 - Detailed bridge analysis requires piers be represented
 - Riverine model requires flow opening is represented
- Small enough to represent the land surface accurately, NOT any smaller
- Terrain model needs to accurately reflect linear features that direct flow. HEC-RAS uses a 2D computational grid as the underlying representation of terrain. 2D cell faces should be aligned with linear feature in the terrain.




Raster Cell Size






Raster Cell Size






HEC-RAS Terrain Fixes





Hydraulic Structure Elevations






Terrain Model Development Summary

- Terrain models are developed as TINs
- Model is typically exported to a Grid for visualization and analysis
 - TINs are more difficult to render
 - TINs are more expensive to store
 - Calculations with TINs more difficult than with rasters
- Grid-cell size determines the effective accuracy of the resulting terrain model
 - How are you going to represent a levee in a raster with a 20ft grid cell?



Terrain in RAS Mapper

- Uses GeoTIFF format
 - Tiled data for more efficient storage
 - Compressed data for efficient storage
 - Pyramided data for fast visualization
 - Allows for on-the-fly inundation mapping
- One Layer for Multiple Terrain Models
- No file size limitations – BigTIFF supported






Terrain in RAS Mapper

- Various formats are supported
 - Binary Floating Point Raster (FLT)
 - Esri Arc/Info Grid format
 - GeoTIFF (still rounds and compresses)
 - Others (e.g. USGS DEM, etc)
- Imported data is rounded to based on precision selected
 - Default is 1/32 (~0.03 ft) (1/128 for metric)
- Recommended that a projection is defined for the RAS Mapper project first.



Projection

- Data used in RAS Mapper must be a common coordinate system.
- Projection will be used to reproject Terrain data that is imported into RAS Mapper.
 - Defined using esri PRJ file.
- Web Imagery will be projected on-the-fly to RAS Mapper coordinate system.





Projection Files

- Not all PRJ files are the same


```
PROJCS["NAD_1983_StatePlane_Pennsylvania_South_FIPS_3702_Feet",  
GEOGCS["GCS_North_American_1983",  
DATUM["D_North_American_1983",  
SPHEROID["GRS_1980",6378137,298.257222101]],  
PRIMEM["Greenwich",0],  
UNIT["Degree",0.017453292519943295]],  
PROJECTION["Lambert_Conformal_Conic"],  
PARAMETER["False_Easting",1968500],  
PARAMETER["False_Northing",0],  
PARAMETER["Central_Meridian",-77.75],  
PARAMETER["Standard_Parallel_1",39.93333333333333],  
PARAMETER["Standard_Parallel_2",40.96666666666667],  
PARAMETER["Latitude_Of_Origin",39.33333333333334],  
UNIT["Foot_US",0.30480060960121924]]
```

```
PROJCS["NAD_1983_StatePlane_Pennsylvania_South_FIPS_3702_Feet",  
GEOGCS["GCS_North_American_1983",  
DATUM["D_North_American_1983",  
SPHEROID["GRS_1980",6378137.0,298.257222101]],  
PRIMEM["Greenwich",0.0],  
UNIT["Degree",0.0174532925199433]],  
PROJECTION["Lambert_Conformal_Conic"],  
PARAMETER["False_Easting",1968500.0],  
PARAMETER["False_Northing",0.0],  
PARAMETER["Central_Meridian",-77.75],  
PARAMETER["Standard_Parallel_1",39.93333333333333],  
PARAMETER["Standard_Parallel_2",40.96666666666667],  
PARAMETER["Latitude_Of_Origin",39.33333333333334],  
UNIT["Foot_US",0.3048006096012192]],  
VERTCS["NAVD_1988",  
VDATUM["North_American_Vertical_Datum_1988"],  
PARAMETER["Vertical_Shift",0.0],  
PARAMETER["Direction",1.0],  
UNIT["Foot_US",0.3048006096012192]]
```



Terrain Importer

- Add files – allows user to select rasters for import
- Order raster files based on Priority on what cell value should be used if there is overlap by the terrain models.
 - Highest Priority to the top





Terrain Importer

- Rounding – Precision which data is stored
- Terrain Filename and Folder
 - name.tilename.tif file for each imported terrain tile
 - name.hdf file contains “stitch” information for data gaps
 - name.vrt file contains statistics info and color ramp info

New Terrain Layer

Set SRS ...

Input Terrain Files

+	Filename	Projection	Cell Size	Rounding	Info
×	channel.tif		5	None	i
	muncie_base.ft		7.77160527153095	(na)	i

↑

↓

Output Terrain File

Rounding (Precision): 1/32 Create Stitches Merge Inputs to Single Raster

Vertical Conversion: Use Input File (Default)

Filename: C:\Temp\2D RAS\1.5 WS - DTM and 2D Mesh\RAS_Model\Terrain\WithChannel.hdf

Create Cancel



Terrain Importer

- Data is projected (translated) and rounded for all data
- Data is pyramided and compressed
- TIN is created for overlapping regions
- Terrain.hdf is the single layer loaded to RAS Mapper

```
Compute Window - Creating Terrain 'Terrain'
```

Importing 1 of 2: BEC_20ft.flt	
Step 1 of 4: Translating to GeoTiff with SRS...	1
Step 2 of 4: Rounding and/or Generating Statistics...	7
Step 3 of 4: Generating Histogram...	2
Step 4 of 4: Adding Overlays...	2
BEC_20ft.flt Import Complete.	14

Importing 2 of 2: BEC_DEM.flt	
Step 1 of 4: Translating to GeoTiff and reprojecting...	26
Step 2 of 4: Rounding and/or Generating Statistics...	1:05
Step 3 of 4: Generating Histogram...	11
Step 4 of 4: Adding Overlays...	13
BEC_DEM.flt Import Complete.	1:56

Final Processing: Terrain.hdf	
Step 1 of 3: Creating Terrain.vrt...	0
Step 2 of 3: Creating Terrain.hdf...	1:17
Step 3 of 3: Creating Stitch-TIN for merging rasters...	6
Terrain Complete	3:34

Close

Questions?