

# HEC-RAS 2D

# Mesh Generation and Refinement

Mark Jensen

Cameron Ackerman, PE, D.WRE


USACE, Institute for Water Resources, Hydrologic Engineering Center





# Overview


- Common Terms
- How to Create a Mesh
- Limitations
- Fixing Mesh Problems
- Hydraulic Property Tables





# Finite Volume Mesh


- Naming Convention
  - Face Points
  - Faces
  - Cells
  - Computation Points (center)





# Mesh Generation


- Define mesh boundary and triangulation (black dots)
- Face Points (red dots) are triangle centroids
- Faces (red lines) connect face points
- Faces are also “Enforced” with internal boundaries





# Create 2D Flow Area Mesh in RAS Mapper

- Meshes are generated from a set of computation points with consideration to polygons and breaklines.
- Steps/Features used to create a mesh:
  - Perimeter Polygon
  - Computation Points
  - Breaklines (Optional)
  - Refinement Regions (Optional)






- Creating a good mesh is an iterative process!



# Editor Access

- Create a New Geometry
- Edit Geometry
- Edit Toolbar
- Select Layer





# Editing



- Add New Feature



- Select/Edit Feature



- Undo/Redo



- Plot Profile



- Tools




- Help





# Add New Feature

- Left-click to start adding a new point, line, or polygon
- Double-click to end a line or polygon
- Pan by switching to Pan tool, Shift key, Middle Mouse, or right-click to re-center.










# Select / Edit

- Select / Edit tool is used to select feature(s) and then begin editing (move, add points, delete, etc).
  - Double-click to Start Editing (Open feature)
  - Double-click to End Editing (Close feature)
- Mouse hover indicates action
  - Green point indicates: Move, Insert, Delete point





# 2D Flow Area


- Draw Perimeter



- 2D Flow Areas
  - Perimeters
  - Computation Points
  - Break Lines
  - Refinement Regions




- 2D Flow Area Editor





- 2D Flow Areas
- Perimeters
- Computation Points**
- Break Lines
- Refinement Regions



# Computation Points

- Generate Computation Points at an even interval
  - Breaklines and Refinement Regions area enforced
- Default n Value
- Hydraulic Table Property Tolerances

2D Flow Area Editor

2D Flow Area: 2DArea

Cell Properties | Connections

Computation Points

Points Spacing (ft) DX: 200 DY: 200

Mesh State = Complete

Number of Cells = 11097  
Average Face Length = 202  
Average Cell Size = 40,765  
Maximum Cell Size = 78,628  
Minimum Cell Size = 31,054

Mesh Status = Success: Existing mesh read from hdf file in 0.029 seconds

Generate Computation Points with All Breaklines

Generate Computation Points without Breaklines

Hydraulic Cell/Face Properties

Default Manning's n Value: 0.06

Compute Property Tables

Hydraulic Property Table Tolerances

2D\_Area


Set the 2D Flow Area's Cell and Face Filter Tolerances for the Hydraulic Table Computations.

Cell Elev-Vol Filter Tol (ft):	0.01
Cell Minimum Area Fraction:	0.01
Face Profile Filter Tol (ft):	0.01
Face Elev-Area Filter Tol (ft):	0.01
Face Conveyance Tol Ratio:	0.02
Face Laminar Depth (ft):	0.2


Defaults OK Cancel



- 2D Flow Areas
- Perimeters
- Computation Points**
- Break Lines
- Refinement Regions



# Computation Points



- Mesh is generated from resultant set of computation points.

Edit Points

Selected Area Edits

Table Tools


	X	Y
1	405880.1458	1804922.839
2	406080.1458	1804922.839
3	406280.1458	1804922.839
4	406480.1458	1804922.839
5	405280.1458	1804722.839
6	405480.1458	1804722.839
7	405680.1458	1804722.839
8	405880.1458	1804722.839
9	406080.1458	1804722.839
10	406280.1458	1804722.839
11	406480.1458	1804722.839
12	405080.1458	1804522.839
13	405280.1458	1804522.839
14	405480.1458	1804522.839
15	405680.1458	1804522.839
16	405880.1458	1804522.839
17	406080.1458	1804522.839
18	406280.1458	1804522.839

OK Cancel



# Create 2D Flow Area Mesh from an existing Storage Area

- Converting Existing Storage Area
  - Click convert button






# Hydraulic Property Tables

- Computation engine uses hydraulic property tables to represent the geometry of the system
- Cells
  - Elevation/Volume
- Faces
  - Elevation/Area
  - Elevation/Wetter Perimeter
  - Elevation/Manning's  $n$
  - (all from station elevation profile)






# Benefits of Hydraulic (Sub-grid) Tables

- Can model small channels in larger cells





# Benefits of Hydraulic (Sub-grid) Tables










# Hydraulic Property Tables

- Computed (once and stored in geometry \*.hdf)
  - From RAS Mapper
  - Before unsteady-flow simulation





# Cells





# Faces

The screenshot displays the RAS Mapper interface. On the left, a tree view shows the project structure under 'Geometries' and 'Results'. The '2D Flow Area' is highlighted in pink. The main window shows a topographic map with a grid of red arrows representing flow direction. A dialog box titled '2D Flow Area - Layer Properties' is open, showing the 'Features' tab. The 'Additional Options' section has 'Mesh Face Numbers' checked. The 'Source File' path is 'C:\HEC Data\RAS\Muncie\RAS Model\Muncie.g01.hdf'.

**Geometries**

- Muncie Geometry - 2D 100ft Grid
  - River
  - Bank Line
  - River Edge Line
  - Junction
  - XS
  - Storage Area
  - 2D Flow Area
  - XS Interpolation Surface

**Results**

- Unsteady - 2D100ft grid 15 sec T
  - Geometry
    - River
    - Bank Line
    - River Edge Line
    - Junction
    - XS
    - Storage Area
    - 2D Flow Area
    - XS Interpolation Surface
    - Depth (02JAN1900 09:10:00)
    - Depth (Max)
    - Arrival Time (1ft days)

**Map Layers**

- Google Hybrid
- MuncieLU

**Terrains**

- TerrainNew

**2D Flow Area - Layer Properties**

Visualization and Information | Features

Point Symbol: [Select...]  
Line Style: [Select...]  
Fill Style: [Select...]

Surface Color Style  
Color Ramp: [Edit]

Label Features  
 Label Features with Attribute Column(s) [Select...]

Messages


Additional Options

- Mesh Edges
- Mesh Cell Numbers
- Mesh Face Numbers
- Mesh Face Point Numbers
- Mesh Dual TIN

Source File  
C:\HEC Data\RAS\Muncie\RAS Model\Muncie.g01.hdf




# Face Profile






# Face Elevation vs Area





# Hydraulic Property Tables

- View from RAS Mapper - '2DFlow Area' in 'Geometry' or 'Results'





# Mesh Limitations

- One face between cells – even on perimeter
- Only one boundary condition per Face
- Except for Lateral structures
  - Lateral structures can stop and start on the same 2D external Face, when connecting 1D reach to a 2D area.




- 2D Flow Areas
- Perimeters
- Computation Points
- Break Lines
- Refinement Regions



# Breaklines

- Breaklines enforce Cell Faces inside of the Mesh.
- Place along linear features that control water movement








# Breaklines

- “Snapping” is part of mesh generation
  - Faces snap to breaklines if they are close enough
- “Enforcing” changes the cell points around a breakline
  - Improves the snapping of the 2D faces to the breaklines
  - Not perfect, might require tighter cell spacing and/or hand graphical editing

# Breakline Properties

- Near Spacing – Initial cell size (approx.) along the breakline.
  - Default value is 2D Area point spacing
- Near Repeats – Repeats cell insertion using Near Spacing a multiple away from the breakline.
- Far Spacing – Max cell size (approx.) of newly added cells.
  - Default value is 2D Area point spacing

- Enforce 1 Cell Protection Radius – Once enforced cells near to the breakline will not be removed through the enforcement of additional breaklines.
  - Include cells added/edited by hand.



The screenshot shows the 'Breakline Editor' dialog box with a table of breakline properties. The table has five columns: Name, Near Spacing, Near Repeats, Far Spacing, and Enforce 1 Cell Protection Radius. There are five rows of data, with the first row selected.

	Name	Near Spacing	Near Repeats	Far Spacing	Enforce 1 Cell Protection Radius
▶ 1	Breakline 1	50	0	100	<input checked="" type="checkbox"/>
2	Breakline 2	50	0	100	<input checked="" type="checkbox"/>
3	Breakline 3	50	0	100	<input checked="" type="checkbox"/>
4	testA	25	1	50	<input checked="" type="checkbox"/>
5	TestB	50	1	100	<input checked="" type="checkbox"/>

Buttons at the bottom: Enforce Selected Breaklines, OK, Cancel.



# Breakline Process

- All points within a computed buffer are removed.
- Cells are added uniformly along the side of breakline.
- Buffer for point removal is computed as:
  - Near Spacing \* Near Repeats
  - + Double Near Spacing size n times until reach Far Spacing size  
(However, take 75% of last cell size so as to not delete too far)

	Name	Near Spacing	Near Repeats	Far Spacing	Enforce 1 Cell Protection Radius
1	Breakline 1	50	0	100	<input checked="" type="checkbox"/>
2	Breakline 2	50	0	100	<input checked="" type="checkbox"/>
3	Breakline 3	50	0	100	<input checked="" type="checkbox"/>
4	testA	25	1	50	<input checked="" type="checkbox"/>
5	TestB	50	1	100	<input checked="" type="checkbox"/>

- A breaklines' area of influence is stopped by a neighboring breakline (will not proceed to opposite side).







# Breakline Examples

- Grid spacing = 100

Near Spacing	Near Repeats	Far Spacing
50		

Near Spacing	Near Repeats	Far Spacing
50	2	

Near Spacing	Near Repeats	Far Spacing
50		200






- 2D Flow Areas
  - Perimeters
  - Computation Points
  - Break Lines
  - Refinement Regions
- 

# Refinement Regions

- Cell Size X,Y – Internal cell size dimension
- Perimeter is treated like a breakline
  - Perimeter Spacing, Near Repeats, Far Spacing, Cell Protection same as for breaklines
- Internal cell size used for perimeter spacing, if not defined







# Refinement Examples

- Grid spacing = 100


Cell Size X	Cell Size Y	Perimeter Spacing
50	50	



Cell Size X	Cell Size Y	Perimeter Spacing
200	200	




Cell Size X	Cell Size Y	Perimeter Spacing
200	200	100






# Refinement Regions and Break Lines to Align Channel Cells





# 2D Flow Area Editor Geometry Editor

- Connections
  - Similar to Storage Area
  - Quick Link to Connections








# Computation Points



- Final mesh is based on final computation point set.
- Enforcement of Breaklines and Refinement Regions modifies existing computation points.
- Can enforce a breakline once, change parameters and enforce again.
  - Each iteration modifies the previous points.
- Point Regeneration will automatically use Breaklines and Refinement Regions.





# Fixing Problems

- If cell spacing is too large, cell faces may not be enforced






# Fixing Problems

- More than 8 sides on a cell.

*2D\_Area: 2 Error(s) - Maximum 8 Faces per Cell [Displaying Local Mesh] [Full Mesh Out-of-Date]*



- Fix by Hand
- Auto “Try Fix” menu option





# Fixing Problems

- Cells need to have exactly one Computation Point (Black Dot)
- Fix graphically by adding more points and/or moving points near perimeter



# Questions?